

Travall Avdelare - BMW X5 (2006-) / X5 M (2010-)

en modellanpassad avdelare av hög kvalitet från Brittiska Travall. Artikelnr TDG1166D

Avdelaren är specifikt designat för att användas med Travalls lastgaller till samma bilmodell!

Avdelaren är ett perfekt alternativ att separera lastutrymmet. Du kan på så sätt förvara lasten i lastutrymmet där det ska vara och på så sätt skydda dig och din hund från lasten vid en eventuell olycka.

Monteringen är snabb, ingen åverkan behöver göras på bilen då den lätt skruvas fast i lastgallret framtill och spänns fast mellan taket och golvet baktill.

Travall är en Brittisk tillverkare av högkvalitativa lastgaller och avdelare med över 30 års erfarenhet.

- Modellanpassade
- Snabb & enkel montering
- Ingen åverkan på bilen krävs
- Skrammel och gnisselfria
- Pulverlackerat stål
- Mörkgrå

Modellspecifikt:

- Kan INTE monteras utan ett Travall® Guard TDG1166
- Går bara att montera i mitten av bagageutrymmet (50/50)
- Kan INTE monteras i bilmodeller där extrahjulet förvarar i bagaget

Passar till:

BMW X5 E70 2006 - 2010
BMW X5 E70 2010 - 2013
BMW X5 F15 2013 - 2018
BMW X5 M E70 2010 - 2013
BMW X5 M F15 2013 - 2018

Travad Dividers

The divider is specially designed to fit with the Travall Guard for the same car model.

The divider is the perfect alternative when you need to divide the rear of your car. With the divider you are able to store the heavy cargo safely and protect you and your dog from it if an accident should occur.

Installing the divider is a quick and easy process. There is no need drilling or other modifications to your car. The divider is screwed to the Travall Guard in the front and the back is holed up by tension against the floor and ceiling.

Travall is a British high quality manufacturer of Guards, Dividers and other vehicle products with over 30 years experience.

- Boot space Divider for use exclusively with Travall Guards.
- Original quality vehicle specific design.
- Supplied with fitting kit and simple-to-follow fitting guide.
- No drilling or vehicle modification needed.

Model specifics:

- Can only be installed in cars with Travall® Guard TDG1166.
- The Guard for these specific models only fits in the center of the boot, giving a 50/50 split only.
- Cannot be fitted to vehicles with space saver spare wheel.

Suitable for models:

BMW X5 E70 2006 - 2010
BMW X5 E70 2010 - 2013
BMW X5 F15 2013 - 2018
BMW X5 M E70 2010 - 2013
BMW X5 M F15 2013 - 2018



Norra Stånggatan 36
58273 Linköping

SE5590566179
VAT.nr
SE559056617901

137-2812

013- 31 02 00

www.hundibil.se
Epost
hej@hundibil.se